Installation Instructions

Eibach Inc. 264 Mariah Circle Corona, CA 92879 USA Tech Support 800-507-2338 ext. 114



E40-82-087-03-01

Vehicle

23+ Toyota GR Corolla

Notes

Kit Contents	Description	Part Number	Quantity
	Rear Sway Bar	AS41-82-087-03-RA	1
	Rear Bushing	UB0571	2
	Lubricant	AR.LUBRICANT	1

Installation Notes

Read all instructions before beginning installation

- Only qualified mechanics experienced in the installation and removal of suspension components should perform this installation.
- Use of a hoist and screw jack is highly recommended and will substantially reduce installation time.
- Never work on or under a vehicle unless it is properly supported by safety stands and wheels are blocked.
- Never use impact wrenches or impact guns to install or remove shock absorber piston components, shafts and Piston rod nuts.
- All Eibach springs should be installed with the Eibach logo right-side-up.
- After Installation, inspect and adjust the following: Wheel Alignment; tire/wheel fender clearance when using aftermarket wheels or tires; brake line clearance and attachments; anti-lock-brake system sensors.



Lift the vehicle in the air with a lift or jack stands.

Disconnect the end links from the sway bar.



Remove the bolt securing the undertray nearest the sway bar. This will give you enough room to push the undertray out of the way to access the sway bar brackets.



Loosen and remove the bolts securing the sway bar brackets.



Remove the clip securing the wire harness for the exhaust valve.



With the rear of the exhaust properly support remove the exhaust hangars.



Lower the exhaust enough to remove the OE sway bar.



Remove the OE sway bar.



Lubricate the provided bushings and install bushings on the sway bar.



Install the Eibach sway bar. You will reuse the OE brackets and hardware.



Install everything in reverse order of removal. Tighten everything to factory specs.



Road test the vehicle and double check that everything is tight.